
creavit®
belgium


Manual for our LED-mirrors

LED-lights

Lighting Kelvin range: 3500k - 6500k

Warm light





Cold light






How to switch on/off the LED-light

1. Use the on/off button to trigger the LED light.

2. To change the color of the light, touch the on/off button for a longer period of time. The light will alternate between cold and warm white.

How to install ROUND mirrors

Requirements:




Drill



Screw driver



Hammer




1. Start by drilling a hole in the wall, where you would like to hang the mirror.

2. To set the screw correctly, use a plastic plug first. Then insert the screw.


3. Be sure to leave 1,5 - 2 cm on the screw to hang the mirror.

4. Once you're done, hang up the mirror and make sure it is secure and stable.



How to install RECTANGULAR mirrors

Requirements:




Drill




Screw driver




Hammer



Tape measure



Pencil



How to use the extra options

Anti-fog:

1. If your mirror has an anti-fog function, you can trigger the heating by pressing the anti-fog button.
2. Once it is turned on, a heating symbol will be displayed.
3. To turn off the anti-fog function, simply press the anti-fog button again.

Setting the clock:

1. To set the time on your mirror, first press the anti-fog button until the digits of the clock start flashing.
2. Then press the on/off button to adjust the hour and leave it free until the minute digits start flashing.
3. Then press the on/off button again to adjust the minutes. Use one touch to adjust per minute.